

## Interim Service & Convenience Checks

<b>Model</b>	Fiesta 2013	<b>Repair/Order No</b>	
<b>Variant</b>	1.0L DURATEC/ECOBOOST/MAN (06/2012 - )	<b>Reg. No.</b>	
<b>Interval</b>	5 Years (62500 ml)	<b>Reg. Date</b>	
		<b>Radio Code</b>	
		<b>Mileage</b>	ml

**Outstanding Field Service Actions. Please ensure they are completed.**  
No Campaign Message(s) found

*L - Labour item - invoice at additional cost*

<b>Driving Vehicle into Workshop</b>	
Instrument gauges, warning control lights and horn	Check operation
Clutch	Check operation/adjust, if necessary (where applicable)
Windscreen, washers, wipers	Check operation and condition, if necessary adjust/repair/renew (separate order required)
<b>Inside Vehicle</b>	
Exterior and respective control lights; instrument cluster illumination	Check operation/condition
Handbrake	Check operation/adjust, if necessary (where applicable)
Seat belts, buckles and stalks	Check operation/condition
Odour filter	Renew
Warning vest	Check availability - if applicable
First aid kit	Check availability and expiry date - if applicable
Warning triangle	Check availability - if applicable
<b>Outside Vehicle</b>	
Road (MOT) test	Check regarding next road (MOT) test due date - if applicable
Emission test	Check regarding next emission test due - if applicable
<b>Under Hood</b>	
Wiring, pipes, hoses, oil and fuel feed lines	Check for routing, damage, chafing and leaks
Engine, vacuum pump, heater and radiator	Check for damage and leaks
Coolant	Check anti-freeze concentration: ___°C
Coolant expansion tank, washer reservoirs and battery	Check/top up fluid levels as necessary - in case of abnormal fluid loss, a separate order is required to investigate and rectify
Battery	Visual check for leaks - in case of abnormal fluid loss, a separate order is required to investigate and rectify (LTS 31 214 4)
Headlamp alignment	Check - adjust alignment, if necessary
Brake fluid	Check/top up fluid levels as necessary - in case of abnormal fluid loss, a separate order is required to investigate and rectify
<b>Under Vehicle</b>	
Engine	Drain oil and renew oil filter
Steering, suspension linkages, ball joints, sideshaft joints, gaiters	Check for damage, wear, security and rubber deterioration
Engine, transmission, rear axle	Check for damage and leaks
Pipes, hoses, wiring, oil and fuel feed lines, exhaust	Check for routing, damage, chafing and leaks
Underbody	Check condition of PVC coating
Tyres	Check wear and condition, especially at tyre wall, note tread depth RF ___mm, LF ___mm, LR ___mm, RR ___mm
Brake system	With wheels on, check brake pads and discs for wear. Check rear brake drums - in case of abnormal fluid loss, a separate order is required to investigate and rectify. (More often under severe duty conditions).
<b>Outside Vehicle</b>	
Engine	Refill engine oil. Reset the oil change indicator, if fitted
Tyres	Adjust pressure
Instant mobility system	Check best before date on tyre sealant - if applicable

## Interim Service & Convenience Checks

<b>Outside Vehicle</b>		
<b>Spare wheel</b>	Adjust pressure, check wear - condition (note tread depth) _____mm	
<b>Tyre pressure monitoring system</b>	Adjust tyre pressures, reset - if applicable	
<b>Luggage compartment lamp</b>	Check operation - if applicable	
<b>Service record and reminder sticker</b>	Update vehicle service record (Service book/Digital Service Record (DSR) and affix sticker to driver side B pillar)	
<b>Extended Period Maintenance</b>		
<b>Brake system</b>	Every 2 years - Renew brake fluid (LTS 12 154 4)	<input type="checkbox"/> L
<b>Air conditioning</b>	Every 3 years - Check temperature at the evaporator outlet tube. Check air conditioning lines for damage and leaks (LTS 34 619 1) (TSB 67/2002)	<input type="checkbox"/> L
<b>Cooling system</b>	Every 10 years - Drain, flush and refill with Super Plus (LTS 24 122 4)	<input type="checkbox"/> L
<b>Camshaft drive belt, tensioner and idlers</b>	Every 150 000 miles/10 years - Renew (LTS 21 304 9 / 21 306 5)	<input type="checkbox"/> L
<b>Auxiliary drive belts</b>	Every 150 000 miles/10 years - Renew (LTS 21 567 5)	<input type="checkbox"/> L
<b>Valve clearances</b>	Every 150 000 miles/10 years - Check. If adjustment is necessary, a separate order is required (LTS 21 213 5)	<input type="checkbox"/> L
<b>Extra Services and Additional Offers * (optional - upon customer request / charged separately)</b>		
<b>AC maintenance package</b>	Air Conditioning (A.C.) system check. Apply A.C. cleaner to air distribution system. (LTS 54 552 4)	<input type="checkbox"/> L
<b>Odour filter plus</b>	Upgrade odour filter to odour filter plus	
<b>Test Drive</b>		
<b>Test drive</b>	Perform test drive after routine service	